

**Note:**

Rear window wiper must be in rest position.

Mark contact point (1) with adhesive tape (A=55 mm / B=490 mm).

Actuate rear window washer unit.

Jet spray must strike marking.

If necessary, adjust spray nozzle (3).

Important!

Do not insert any pointed objects into spray nozzle (3) (risk of damage).

Open protective cap (2).

Adjust spray nozzle (3) with a suitable tool until jet spray strikes marking.

If necessary, remove adhesive residue from rear window.

Fill up with washer fluid.