

**Note:**

Rear window wiper must be in rest position.

Mark contact point (1) with adhesive tape (A=55 mm / B=490 mm).

Actuate rear window washer unit.

Jet spray must strike marking.

If necessary, adjust spray nozzle (3).

**Important!**

Do not insert any pointed objects into spray nozzle (3) (risk of damage).

Open protective cap (2).

Adjust spray nozzle (3) with a suitable tool until jet spray strikes marking.

If necessary, remove adhesive residue from rear window.

Fill up with washer fluid.