



Release screws (1).

Release nuts (2) and remove underbody panelling (3).