
*Necessary preliminary tasks:*

- Partially remove front left wheel arch trim

*Note:*

Catch any escaping washer fluid if necessary.

Disconnect plug connection (1).

Detach hoses (2) from windscreen washer pump (3).

Pull windscreen washer pump (3) out of fluid reservoir for windscreen washer system.

*Installation:*

Replace strainer in windscreen washer pump (3).

Coat sealing ring of windscreen washer pump (3) with antiseize agent.

Make sure hoses are laid without kinks.

Fill fluid reservoir.